

# Quick Start Guide: Adding NVRs, DVRs and IP Cameras through P2P

[This note applies to all NVRs, DVR and IP Cameras with P2P Services].



## Overview

*This document reviews the 'P2P' (Peer to Peer) service and how to add cameras to easy access and control. The P2P ability provides an easy way for remotely accessing your devices without the need to configure a router or modem. Before starting, be sure to plug in your device to an existing network that has full internet access. Follow the instructions below to start registering your devices through our P2P server!*

## Guide

- **Step 1** – First, navigate on a personal computer to [www.myeasyip.com](http://www.myeasyip.com) . Click on the 'Sign Up' option to create a free account on our P2P server. Once done, you will have access to add your DVR, NVR or IP cameras to your account.

A screenshot of a web interface for logging in or signing up. The interface has two tabs: 'User' and 'Device'. Under the 'User' tab, there are two input fields: 'Username' with a person icon and 'Password' with a lock icon. Below these fields is a checkbox labeled 'Stay signed in' and a link labeled 'Forgot Password?'. At the bottom, there are two buttons: an orange 'Login' button and a blue 'Sign Up Now' button. Two red arrows point from the 'Login' button down to the 'Sign Up Now' button.

- **Step 2** – Once logged in, you can simply click the **'Add'** button towards the left side so to add your device to your account. Simply input a unique **'Device Name'**, **'Serial Number'** (**'SN'**) and the **'Device User'** (use **'admin'** by default) and **'Password'** (use **'admin'** by default). Note that the serial number can be found on the bottom of the unit, the boxing or through its network connection. If the device in question is connected to your network and has internet access, you should see the newly added device on your list. If the status indicates **'Online'**, you may click on the **'Play'** arrow (▶) to launch the web interface to control it.



- **Step 3** – You may also access your NVR or DVRs **'Main Menu' → 'Settings' → 'Network' → 'P2P Settings' (P2P)** section. There you should see a **'Enable'** option and a QR code bar. Make sure you enable the option first and use the mobile application (ICVIEW, ICRSS Pro or other ICRealtime mobile applications) to scan the QR code. Make sure on the mobile application when adding a new device, your **'register mode'** is set on P2P. Fill in the rest of the information as you did from the first step and you should be able to immediately stream channels from the recorders.



- **Step 4** – For IP Cameras, you obtain the same QR code to register it but through its web service. Use the serial number to add it to your [www.myeasyip.com](http://www.myeasyip.com) account or once you have it attached to your network, open a web browser and type in the default IP address such as 'http://192.168.1.108'. If having trouble finding it on your network use our '**IP Auto Search**' tool (download from our support website [www.icrealtime.com/support](http://www.icrealtime.com/support)). Once you login to the web service of the camera, navigate to '**Network**' → '**TCP/IP**' and click on '**P2P**'. You should find the same menu page as our recorders where you can enable P2P and scan your QR in to your phone for direct access.



- **Step 5** – Lastly, you may use our SmartICRSS client on your PC or Mac to import all registered devices from [www.myeasyip.com](http://www.myeasyip.com). If you have not done so already, visit our support site at [www.icrealtime.com/support](http://www.icrealtime.com/support) and download the latest version of SmartICRSS. Once installed, the '**Devices**' menu from the '**Home Page**'. You should see an '**Import**' option at the bottom. Click this and choose the '**MyEasyIP**' tab. Simply input the e-mail address you signed up with and password that goes along with it. Click '**Import**' after this and if successful, it will import all registered devices prior to signing up. Go to '**Live View**' from the '**Home Page**' to login and stream the cameras/recorders.



For detailed instructions visit [support](http://www.icrealtime.com/support) or the [forum](http://www.icrealtime.com/forum)

IC Realtime LLC

3050 N Andrews Avenue Extension  
Pompano Beach, FL 33064  
(866) 997-9009

[www.icrealtime.com](http://www.icrealtime.com)

Designs and specifications subject to change without notice. Copyright © 2015 IC Realtime, LLC. All rights reserved.